



- ⒸZ Návod k instalaci a k použití
- Ⓔ Instrucciones de montaje y de manejo
- Ⓕ Instructions de montage et mode d'emploi
- ⒼB Installation and operating instructions
- Ⓕ Szerelési és használati utasítás
- Ⓘ Istruzioni di montaggio e per l'uso
- ⒼL Montagehandleiding en Gebruiksaanwijzing
- ⒼO Monterings- og bruksanvisning
- ⒼL Instrukcja montażu i obsługi
- ⒶU Руководство по монтажу и эксплуатации
- ⒶK Návod na montáž a obsluhu






DESPF




DESSPF


**DIN EN 806
DIN EN 1717
DIN 1988
Global Standards**

i
VIGOUR
Montage und
Bedienanleitung






1.



2.



3.

