





V3DEBV

Einhand-AP-Brausebatt. vertikal derby V3
chrome, VIGOUR

Single-lever shower mixer vert. derby V3
chromed VIGOUR

1	YVG7911405	Hebel derby V3 für Einhandbatterie VIGOUR	Lever derby V3 for single mixer VIGOUR
1.1	YVG92204600	Gewindestift derby / derby style für Farbset Waschtischbatt. VIGOUR	Set screw derby / derby style Finish set for basin mixer VIGOUR
1.2	YVG93019705	Markierungsstopfen derby / derby style Armaturen VIGOUR	Marking plug derby / derby style for VIGOUR faucets
2	YVG93090805	Abdeckkappe derby / derby style für Waschtischbatt. VIGOUR	Cover cap derby / derby style for basin mixer VIGOUR
3	YVG93033300	Spannschraube derby V3 für Einhandbatterie VIGOUR	Locking screw derby V3 for single mixer VIGOUR
4	YVG7623000	Steuereinheit k36 f. derby V3 / V3 plus für Brausebatt. u. WT Wandbatterie VIG	Control unit k36 f. derby V3 / V3 plus for derby V3 faucets VIGOUR
5	YVG7489300	Brauseanschlussnippel derby / derby plus für Einh. AP- Brausebatt. VIGOUR	Shower connect. thread derby/derby style Surface mounted single lever bath mixer
5.1	YVG7510600	Rückflussverhind. derby style / Safe-Tec Einh.- AP-Brause- u. Spültischbat.VIGOUR	Non return valve derby style /Safe-Tec Surface mounted shower, and sink mixer
6	YVG7533505	Wandarmaturenanschluss derby für Einh.- Wandbatt. VIGOUR	Union nut for derby for wall mounted single lever VIGOUR
7	YVG7380705	Rosette derby V3 / V3 plus f. Farbset Badebett. u. Sinkbatt. VIGOUR	Escutcheon derby V3 / V3 plus bath u. sink finish set VIGOUR
8	YVG7655100	S-Anschluss für derby / derby style Armaturen VIGOUR	S-Unions for derby / derby style Faucets VIGOUR



Single-lever shower mixer vert. derby V3
chromed VIGOUR

[illegible]