




DESL	Einhand-Waschtiszbatterie derby style L-Auslauf schwenkb. m. Abl. verchr. VIG	Basin mixer derby style V-Spout pivoted w. drain set chr. VIGOUR
------	--	---

1	YVG7343705	Hebel derby style für Spültiszbatterie seitenbedient VIGOUR	Lever derby style for sink mixer lateral control VIGOUR
1.1	YVG92204600	Gewindestift derby / derby style für Farbset Waschtiszbatt. VIGOUR	Set screw derby / derby style Finish set for basin mixer VIGOUR
1.2	YVG93089705B	Markierungsstopfen derby / derby style Armaturen VIGOUR	Marking plug derby / derby style for VIGOUR faucets
2	YVG7344205	Auslauf derby style f. Waschtischarmatur mit L-Auslauf VIGOUR	Spout derby/derby style f. basin mixer with L-spout VIGOUR
2.1	YVG7339005	Strahlregler verstellbar M24x1 für derby und derby style Armaturen VIGOUR	Flow disk adjustable M24x1 for derby and derby style faucets VIGOUR
2.2	YVG92201435	Gewindestift derby / derby style für Farbset Waschtiszbatt. VIGOUR	Set screw derby / derby style Finish set for basin mixer VIGOUR
3	YVG93090805	Abdeckkappe derby / derby style für Waschtiszbatt. VIGOUR	Cover cap derby / derby style for basin mixer VIGOUR
4	YVG93013000	Spannschraube derby / derby plus Einh.Spültisch- u. Waschtiszbatt.VIGOUR	Locking screw derby / derby style single lever sink and basin mixer VIGOUR
5	YVG7560700	Keramik Kartusche Ø36mm für derby und derby style Armaturen VIGOUR	Ceramic cartridge Ø36mm for derby and derby style faucets VIGOUR
6	YVG7343300	Dichtungssatz derby / derby style für V-Auslauf VIGOUR	Set od seals derby / derby style for V-Spout VIGOUR
7	YVG7338805	Zugstange derby / derby style Waschtisch- und Bidetbatterie VIGOUR	Pull rod for derby / derby style and derby style faucets VIGOUR

