



DEBV

Einhand-Aufputz-Brausebatterie derby  
vertikal o. Brausegarn. verchr. VIGOUR

surface mounted shower mixer derby  
vertikal without Shower set chr. VIGOUR

YVG7338305	Hebel derby für AP-Brausebatterie und WT- und Spültischwandbatterie VIGOUR	Lever derby conc. shower mixer Basin- and sink wall mixer VIGOUR
YVG7345205	Wandarmaturenanschluss derby/derby plus für Einh.- Wandbatt. VIGOUR	Union nut for derby / derby plus for wall mounted single lever VIGOUR
YVG7421805	Rosette derby / derby style / derby plus für Aufputzbatterien VIGOUR	Escutcheon derby /derby style/derby plus for surface mounted mixers VIGOUR
YVG7489300	Brauseanschlussnippel derby / derby plus für Einh. AP- Brausebatt. VIGOUR	Shower connect. thread derby/derby style Surface mounted single lever bath mixer
YVG7510600	Rückflussverhind. derby style / Safe-Tec Einh.- AP-Brause- u. Spültischbat.VIGOUR	Non return valve derby style /Safe-Tec Surface mounted shower, and sink mixer
YVG7560700	Keramik Kartusche Ø36mm für derby und derby style Armaturen VIGOUR	Ceramic cartridge Ø36mm for derby and derby style faucets VIGOUR
YVG7655100	S-Anschluss für derby / derby style Armaturen VIGOUR	S-Unions for derby / derby style Faucets VIGOUR
YVG92204600	Gewindestift derby / derby style für Farbset Waschtischbatt. VIGOUR	Set screw derby / derby style Finish set for basin mixer VIGOUR
YVG93013000	Spannschraube derby / derby plus Einh.Spültisch- u. Waschtischbatt.VIGOUR	Locking screw derby / derby style single lever sink and basin mixer VIGOUR
YVG93089705B	Markierungsstopfen derby / derby style Armaturen VIGOUR	Marking plug derby / derby style for VIGOUR faucets
YVG93090805	Abdeckkappe derby / derby style für Waschtischbatt. VIGOUR	Cover cap derby / derby style for basin mixer VIGOUR