




V3DES WB130

Einhand-Spültisch-Wandbatterie derby V3 Single-lever sink mixer derby V3
sw. Ausl 130mm m. Hebel geschl.chrom VIC swv spout 130 mm closed lever chromed

1	YVG7909205	Hebel derby V3 für Brausebatterie und Bade- und Spültischwandbatterie VIGOUR	Lever derby V3 for shower mixer and Basin- and sink wall mixer VIGOUR
2	YVG7733805	Strahlregler M24x1Z für derby V3 Armaturen VIGOUR	Aerator M24x1Z for derby V3 for faucets VIGOUR
3	YVG7226405	Abdeckkappe+Spannschraube derby V3 Bade- und Spültischwandbatterie VIGOUR	Lever derby V3 for shower mixer and Basin- and sink wall mixer VIGOUR
4	YVG7623000	Steuereinheit k36 f. derby V3 / V3 plus für Brausebatt. u. WT Wandbatterie VIG	Control unit k36 f. derby V3 / V3 plus for derby V3 faucets VIGOUR
5	YVG7376105	Rosette derby V3 / V3 plus f. Farbset Badebett. u. Sinkbatt. VIGOUR	Escutcheon derby V3 / V3 plus bath u. sink finish set VIGOUR
6	YVG7655100	S-Anschluss für derby / derby style Armaturen VIGOUR	S-Unions for derby / derby style Faucets VIGOUR